

M5R1-15A
M5R1 **M5R1-19A**
M5R1 **M5R1-21A**
M5R1 **M5R1-36**
M5R1



M5R2-15A
M5R2 **M5R2-19B**
M5R2 **M5R2-36**
M5R2 **M5R2-40A-2ATC**



M5R2-156(W) **WT296-8** **WT296-11** **WT296-12A**



WT296-16AN



PART NO.	DESCRIPTION	MODEL
E69Z-7017A	INPUT SHAFT (=TK5-16B) 11-1/2" OVERALL LENGTH 23S/19T/42T	TK5 (LATE)
E8TZ-7017D	INPUT SHAFT 23/20/36 (=MIT-16D)	-
E8TZ-7101-A	3RD SPEED GEAR 29T/42T (=M5R1-11)	M/S M5R1 L32T L42S
E8TZ-7102A	2ND SPEED GEAR 32T/42T (=M5R1-21)	M5R1
E8TZ-7112B	5TH GEAR (=M5R2-18) 27T/38T	M5R2
E8TZ-7113-D	CLUSTER GEAR 29/16/24/32/38 (=M5R1-8)	M5R1
E8TZ-7183	5-R SLIDER (=M5R2-15) 42T	M5R2
E8TZ-7NO40B	REVERSE GEAR 15T/42T (=M5R2-36)	M5R2 (EARLY)
F1TZ-7124H	3-4 HUB51T/32T+SLEEVE 51T (=M5R2-2.5)	M5R2
F2TZ-7127	5TH REV. SLIDER (=M5R1-15) 36T	M5R1 (EARLY)
FOTZ-7017A	INPUT SHAFT 23/23/42 (=M5R1-16A)	M5R1 L23T L22(42)S
FOTZ-7017B	INPUT SHAFT 23/23/42 (=M5R1-16)	M5R1 L23T L22(42)S
FOTZ-7101A	3RD SPEED GEAR 27T/42T (=M5R1-11A)	M5R1 4.0L L27T L42S
FOTZ-7102A	2ND GEAR NO ID 31T/42T (=M5R1-21A)	M5R1 , 92 FORD EXPLORER MANUAL
FOTZ-7113A	CLUSTER GEAR 38/34/25/17/29 (=M5R1-8A)	M5R1
M5R1-36	REVERSE GEAR 17T/36T	M5R1
M5R1-11	3RD GEAR 29T/42T	M5R1
M5R1-11A	3RD GEAR 27T/42T	M5R1
M5R1-15	SLEEVE 36T	M5R1
M5R1-18A	SMALL SPEED 23T/34T GEAR+BUSHING	M5R1
M5R1-19A	SPEED GEAR 48T/30T	M5R1
M5R1-2	MAIN SHAFT 25/34/40/32	M5R1 88-97 RANGER 2.3L
M5R1-2.5	SYNC.ASSY 3-4 (HUB42T/32T+SLEEVE42T)	M5R1 RANGER
M5R1-21	2ND SPEED GEAR(=E8TZ-7102A) 32T/42T	M5R1
M5R1-36	SPEED GEAR 17T/36T	M5R1
M5R1-40	HUB30T/29T +SLEEVE 30T	M5R1
M5R1-8	COUNTER GEAR 29T/16T/24T/32T/38T (E8TZ-7113D)	M5R1
M5R2-11	3RD GEAR 30T/51T	M5R2
M5R2-15	SLEEVE 42T	M5R2
M5R2-156	BUSHING	-
M5R2-15A	SLEEVE 33T	M5R2
M5R2-16	INPUT GEAR 10T/24T/51T	M5R2